



Ford Ranger PX2 PX3 & Equivalent Ford Everest Phone/UHF/GPS Bracket Fitting Instructions

Tools Needed



- Ratchet and Extension with 7mm Socket
- Trim removal tool
- Very Carefully insert plastic trim tool between the base of the drivers left hand air-con vent and the dash. Once inserted, twist the tool and you will hear the vent pop out of its fastening clips.
- Remove the vent carefully from the dash.
- Using a 7mm socket and ratchet, remove the 7mm head bolt that sits in the top left hand corner of the air con vent void.
- Insert the bracket into the hole and line up the eyelet of the bracket with the bolt hole and ensure that the protruding plastic trim pushes into the rectangular hole in the bracket as pictured. In some cases, you may need to use a small screwdriver to prize this plastic part to fit in the rectangular hole in the bracket.
- Fit 7mm head bolt back into the hole and tighten with your ratchet.
- Now re-position vent back in place. *Tech Tip - Insert your cables into the vent if you want to hide the cables. They can be guided into the vent and down through to where your left knee is for a tidy install. A USB extender may be required to reach your apple car play USB in the centre console.
- Push firmly on the vent until you hear it clip back in place.
- For a detailed video on this install visit our website on www.out-there-n-back.com.au or our Facebook page.